

## TA012 — Automotive Break Out Lead



The TA012 break out lead enables voltage readings to be taken from the numerous sensors in the engine compartment. The break out lead is simply connected into the existing cable loom, the output signal can then be taken from the two 4 mm banana plugs into the [automotive oscilloscope](#) using the TA000 test lead.

**Note:** a [TA000](#) will be required to convert the 4 mm banana plug connection on the TA012 into a BNC connector suitable for plugging into the PicoScope.