

Fuse Extension Leads

How do you connect your amp probe to a circuit?
Extend it and loop it!



Overview

Do you need to measure the current through a circuit but can't find anywhere on the vehicle where you can connect your current clamp?

Fuse extension leads are a simple accessory that can save you valuable time.

Fuse extension leads are quick and easy to use:

1. Remove the fuse (of the circuit you wish to test) from the fusebox.
2. Replace it with a fuse extension lead.
3. Insert the fuse into the extension lead.
4. Connect your Pico current clamp to the extension lead to measure the current draw.

Contents

Includes 2 fuse extension leads:

- ATC fuse extension lead
- mini-ATC fuse extension lead

Works with all low current probes.

